



BUTTON LOOPS

EL90*/EL900* - 1/2" WIDTH with 3/8" SPACING*
LOOP IS ELASTIC AND HEADER IS NON-ELASTIC



EL1190/EL119* - 1/2" WIDTH with 1/2" SPACING*
NON-ELASTIC LOOPS AND HEADER



EL1140/EL114* - 3/8" WIDTH with 1/2" SPACING*
LOOP IS ELASTIC AND HEADER IS NON-ELASTIC



EL1150/EL115* - 1/2" WIDTH with 1" SPACING*
LOOP IS ELASTIC AND HEADER IS NON-ELASTIC



EL118* - 1/2" WIDTH with 1/4" SPACING*
LOOP IS NON-ELASTIC AND HEADER IS ELASTIC



*Spacing is the distance between the center of two loops. Button loops are actual size if printed on 8.5" x 11" paper
If you have any questions, please call us at 800-654-2235 or email customerservice@wawak.com.